



EMAS[®]
BRAZIL

A1 CHAIN BREAK & CLUTCH COVER




Part A		Brake Bar & Chain Sprocket Cover	QTY
1		Brake Bar	1
2		Sleeve	1
3		Washer M5	2
4		Screw M5*12	2
5		Chain Sprocket Cover Assy	1
6		Pin	1
7		Clip ϕ 5	1
8		Self-tapping Screw M3*8	1
9		Spring	1
10		Lever	1
11		Brake Band	1
12		Brake Cover	1
13		Self-tapping Screw M3.5*8	6
14		Inner Side Plate(Right)	1
16		Chain Sprocket Cover	1
17		Sticker	1
18		Screw Nut	2

B CLUTCH & OIL PUMP




PART B		Clutch & Oil Pump	QTY
2		Clutch Spring	1
8		Screw M4*14	2
9		Connector - Oil Outlet	1
12		Oil Filter	1

C1 CYLINDER COVER




PART C		Shroud(B)	1
--------	--	-----------	---

D MUFFLER
CYLINDER PISTON
CRANKSHAFT




PART D		Muffler, Cylinder, Piston	QTY
1		Muffler	1
2		Screw M5*10	4
3		Screw	1
7		Spark Plug	1
8		Screw M5*20	4
11		Cylinder ϕ 45 (509)	1
13		Nut - Muffler	2
14		Gasket - Cylinder	1
16		Piston Ring ϕ 45	2
18		Piston Assy ϕ 45	1
20		Screw M5*14	2
21		Plate	2
23		Oil Seal (Steel)	2

E CARBURETOR & AIR FILTER




PART E		Carburetor & Air Filter	QTY
1		Spring	1
2		Air Filter	1
3		Screw M5*50	2
4		Intake Elbow	1
5		Sleeve air filter	1
6		Air Filter Support	1
7		Grommet	1
8		Screw M5*10	1
9		Carburetor support metal	1
10		Carburetor	1
11		Sleeve	1
12		Screw Nut M5	2
13		Collor Nut M5*12	2
15		Sleeve	1
16		Manifold	1

F CRANKCASE




PART F		CRANCKASE	QTY
1		Sleeve	1
2		Choke Rod	1
3		Grommet	2
4		Throttle Rod	1
5		Screw M4*12	2
6		Inner Side Plate (Left)	1
7		Crankcase	1
8		Element copper	1
9		Valve	1
10		Sleeve	1
11		Bumper Strip	1
12		Spring	1
13		Pin - Crankcase	2
14		Screw	2
15		Gasket - Crankcase	1
16		Screw M8*10	2
18		Screw M5*12	3
19		Bumper Spike	1
20		Chain Catcher	1
21		Locker	3
22		Screw M5*20	4
23		Screw M5*25	2
24		Oil Cap	1
25		Oil Rope	1
26		Sealing Ring	1

G FUEL TANK




PART G		Feul Tank	QTY
1		Fuel Tank	1
2		Fuel Hose	1
3		Fuel Filter	1
4		Breathing Valve	1
5		Connector	1
6		Element	1
7		Valve	1
8		Valve seat	1
9		Triggler Interlock	1
10		Flat Spring	1
11		Throttle Triggler	1
12		Pin ϕ 3*25	1
13		Annular Buffer	4
14		Screw M5*12	4
15		Sleeve	1
16		Fuel Cap	1
17		Fuel Rope	1
18		Sealing Ring	1
19		Sticker	1

H IGNITION SYSTEM





PART H		Ignition System	QTY
1		Ignition Module	1
		Flywheel	1
2		Spark Plug Boot	1
3		Screw M5*20	2
4		Short Circuit Wire	1
5		Stop Switch	1
6		Nut M10	1

J HANDLES



PART J		HANDLE	QTY
12		Handle Bar	1
13		Screw M5*17	4

K1 STARTER



PART K1		STARTER	QTY
1		Washer	1
2		Starter Assy	1
3		Starter Grip	1
4		Bushing	1
5		Starter Cover	1
6		Screw M5*12	1
7		Shaft Joint	1
8		Bearing 10*15*12	1
9		Spring	1
		Starter Rope	1
10		Starter Pulley	1
11		Self-tapping Screw	2
		Rewind Spring	1
12		Rewind Spring Cover	1
13		Screw M5*20	4
14		Model Plate	1