

***EMAS***<sup>®</sup>  
***BRAZIL***

# A

\*compl 503 73 66-01



③\*503 80 27-01

\*503 20 26-16

501 76 80-01\*

\*503 52 08-01

③\*506 16 48-01



compl 503 72 74-01\*③

720 12 33-51\*

503 21 28-10\*

501 87 53-03\*

503 70 99-01\*



503 70 40-01\*

\*501 87 47-01

725 53 27-55

503 22 00-01

503 70 46-01\*

503 70 47-01\*

\*503 21 28-10

503 73 05-01\*

501 51 72-01\*

503 59 09-01

503 59 07-01

# L

501 40 34-02

501 77 85-01

compl 503 65 09-01(3/8"x7)  
compl 501 67 41-01(3/8"x8)

501 51 38-01  
503 23 00-13

725 52 93-56  
\*503 26 02-04

501 51 48-01

501 59 80-02(3/8"x7)  
505 30 36-61(3/8"x8)

503 25 34-01  
501 83 17-01

501 53 59-01

501 83 15-03(3/8"x8)  
501 83 15-04(3/8"x7)



\*compl 501 51 25-01

501 51 36-01\*  
720 12 37-50\*

501 51 33-01\*

501 51 32-01\*

501 51 31-01\*

501 51 34-01\*

503 23 00-16\*

503 23 10-01\*

501 51 37-01\*

501 51 39-01\*

734 48 48-01\*

\* 735 31 07-20\*


740 42 21-00\*

501 28 85-01\*

721 42 03-25\*


501 51 99-01

501 54 41-02





**B**


\*compl 503 61 00-03  
 \*compl 503 61 00-04(USA)

**C**


\*compl 503 53 20-71

**G****H**


\*compl 503 61 33-71

**M**


\*compl 501 77 99-01



**D** 




**J** 




# E

\*compl 501 69 90-10




# K

\*compl 503 61 55-71



**O**

\*compl 503 28 04-07


**Tillotson HS 254 B**

② 501 49 48-02


**Packningssats, förgasare**  
**Set of gaskets, carburettor**  
**Dichtungssatz, vergaser**  
**Jeu de joints, carburettor**

**R**

**Leveras endast som reservdel**  
**Delivery as spare part only**  
**Nur als Ersatzteil lieferbar**  
**Livvable seulement comme pièce de rechange**  
**Solo como repuesto**  
**Zasilá se jenom jako náhradní díl**




501 44 44-01  
 501 44 45-01



**P**






Tillbehör  
Accessories  
Zybehöre  
Accessoires  
Accesorios  
Pomucky





**S**

\*compl 501 68 60-04  
\*compl 501 68 60-07(USA)

**Up to 1070001 (1991)**



\*compl 501 68 52-63





T





## From 107001 - 3481259 (1991) (1993)

\*compl 501 52 84-02




## From 107001 - 4502561 (1991) (1994)

\*compl 503 57 28-01



## Up to 4230007 (1994)



MODEL 61

| PART NUMBER  | SQUARE NOTE | PART NUMBER  | SQUARE NOTE | PART NUMBER  | SQUARE NOTE | PART NUMBER  | SQUARE NOTE |
|--------------|-------------|--------------|-------------|--------------|-------------|--------------|-------------|
| 501 08 17-01 | J           | 501 52 95-02 | K           | 503 21 29-06 | S           | 503 66 91-01 | G           |
| 501 20 15-02 | K           | 501 53 38-03 | D           | 503 21 60-25 | C           | 503 69 76-01 | M           |
| 501 22 03-01 | O           | 501 53 45-03 | E           | 503 21 90-08 | S           | 503 70 40-01 | A           |
| 501 22 04-01 | O           | 501 53 59-01 | L           | 503 22 00-01 | A           | 503 70 46-01 | A           |
| 501 22 05-01 | O           | 501 53 71-01 | M           | 503 22 10-02 | T           | 503 70 47-01 | A           |
| 501 22 08-01 | O           | 501 54 41-02 | L           | 503 22 10-11 | J           | 503 70 99-01 | A           |
| 501 22 09-01 | O           | 501 59 80-02 | L           | 503 22 20-05 | S           | 503 71 79-01 | M           |
| 501 22 12-01 | O           | 501 62 66-02 | M           | 503 23 00-01 | DS          | 503 72 31-01 | M           |
| 501 22 13-01 | O           | 501 62 68-01 | M           | 503 23 00-08 | T           | 503 72 74-01 | A           |
| 501 22 14-01 | O           | 501 62 87-01 | E           | 503 23 00-13 | L           | 503 73 05-01 | A           |
| 501 22 15-01 | O           | 501 62 96-01 | E           | 503 23 00-16 | L           | 503 73 39-01 | CHT         |
| 501 22 17-01 | O           | 501 63 06-01 | K           | 503 23 00-42 | JM          | 503 73 66-01 | A           |
| 501 22 20-01 | O           | 501 65 76-01 | S           | 503 23 01-01 | J           | 503 80 27-01 | A           |
| 501 22 21-01 | O           | 501 65 92-01 | K           | 503 23 10-01 | L           | 503 90 14-01 | J           |
| 501 22 23-01 | O           | 501 67 32-01 | J           | 503 23 43-02 | K           | 503 98 74-01 | B           |
| 501 22 24-01 | O           | 501 67 35-01 | J           | 503 23 51-08 | C           | 504 35 86-10 | D           |
| 501 22 25-01 | O           | 501 67 41-01 | L           | 503 23 72-02 | J           | 505 30 36-61 | L           |
| 501 25 09-02 | S           | 501 68 52-63 | S           | 503 25 34-01 | L           | 505 31 66-05 | O           |
| 501 25 10-02 | D           | 501 68 60-04 | S           | 503 26 02-04 | LM          | 506 16 48-01 | A           |
| 501 26 85-01 | O           | 501 68 60-07 | S           | 503 27 90-04 | M           | 720 12 33-00 | T           |
| 501 26 89-01 | O           | 501 68 64-01 | S           | 503 28 04-07 | DO          | 720 12 33-51 | A           |
| 501 26 90-01 | O           | 501 68 65-01 | S           | 503 28 90-15 | C           | 720 12 37-50 | L           |
| 501 27 82-01 | E           | 501 69 11-01 | O           | 503 40 54-01 | C           | 720 13 07-10 | M           |
| 501 28 85-01 | L           | 501 69 17-01 | P           | 503 40 56-01 | S           | 721 42 03-25 | L           |
| 501 28 92-01 | S           | 501 69 90-10 | E           | 503 41 92-01 | O           | 721 42 12-26 | E           |
| 501 29 64-02 | D           | 501 69 94-01 | E           | 503 44 32-01 | E           | 721 42 52-50 | T           |
| 501 29 65-01 | S           | 501 76 80-01 | A           | 503 44 50-01 | M           | 724 12 87-59 | G           |
| 501 29 66-01 | S           | 501 77 34-01 | E           | 503 44 51-01 | D           | 725 52 93-56 | DLS         |
| 501 40 34-02 | L           | 501 77 35-01 | E           | 503 46 59-01 | T           | 725 53 27-55 | AME         |
| 501 42 41-01 | E           | 501 77 68-01 | S           | 503 47 69-01 | G           | 725 53 31-55 | M           |
| 501 42 71-01 | O           | 501 77 82-02 | T           | 503 48 63-01 | O           | 725 53 37-55 | M           |
| 501 43 14-02 | E           | 501 77 85-01 | L           | 503 48 98-01 | D           | 725 53 41-55 | M           |
| 501 44 44-01 | R           | 501 77 99-01 | M           | 503 51 15-03 | J           | 725 53 70-55 | G           |
| 501 44 45-01 | R           | 501 80 71-01 | D           | 503 52 08-01 | A           | 734 48 48-01 | L           |
| 501 48 52-01 | O           | 501 80 71-05 | D           | 503 53 20-71 | C           | 735 31 07-20 | L           |
| 501 48 54-02 | J           | 501 80 71-06 | D           | 503 53 32-01 | O           | 735 31 08-20 | A           |
| 501 49 48-02 | O           | 501 81 43-01 | E           | 503 53 36-01 | O           | 735 88 06-00 | T           |
| 501 51 22-04 | C           | 501 81 48-01 | M           | 503 53 37-01 | O           | 737 43 12-00 | C           |
| 501 51 25-01 | L           | 501 81 56-01 | D           | 503 53 39-01 | O           | 738 22 02-25 | H           |
| 501 51 31-01 | L           | 501 81 57-01 | M           | 503 53 58-01 | M           | 740 42 21-00 | LS          |
| 501 51 32-01 | L           | 501 81 99-01 | J           | 503 53 59-01 | G           |              |             |
| 501 51 33-01 | L           | 501 82 17-01 | O           | 503 53 90-02 | C           |              |             |
| 501 51 34-01 | L           | 501 82 18-01 | O           | 503 54 39-01 | K           |              |             |
| 501 51 36-01 | L           | 501 83 15-01 | T           | 503 57 22-01 | T           |              |             |
| 501 51 37-01 | L           | 501 83 15-02 | T           | 503 57 28-01 | T           |              |             |
| 501 51 38-01 | L           | 501 83 15-03 | L           | 503 57 29-01 | T           |              |             |
| 501 51 39-01 | L           | 501 83 15-04 | L           | 503 57 30-01 | T           |              |             |
| 501 51 48-01 | L           | 501 83 17-01 | L           | 503 57 31-01 | T           |              |             |
| 501 51 54-01 | B           | 501 83 18-01 | T           | 503 57 76-01 | E           |              |             |
| 501 51 61-02 | S           | 501 83 98-01 | J           | 503 57 87-01 | O           |              |             |
| 501 51 62-01 | S           | 501 87 47-01 | A           | 503 57 89-01 | EM          | N            |             |
| 501 51 72-01 | AM          | 501 87 53-01 | T           | 503 58 99-01 | S           |              |             |
| 501 51 80-02 | E           | 501 87 53-03 | A           | 503 59 03-02 | S           |              |             |
| 501 51 81-02 | E           | 501 91 57-02 | S           | 503 59 07-01 | AT          |              |             |
| 501 51 97-02 | E           | 502 01 22-01 | O           | 503 59 08-01 | M           |              |             |
| 501 51 99-01 | L           | 503 10 24-02 | S           | 503 59 09-01 | A           |              |             |
| 501 52 04-02 | K           | 503 10 24-05 | K           | 503 59 92-05 | G           |              |             |
| 501 52 25-04 | S           | 503 17 81-01 | R           | 503 59 92-07 | G           |              |             |
| 501 52 26-06 |             | 503 20 02-10 | G           | 503 60 43-01 | O           | N            |             |
| 501 52 49-01 | S           | 503 20 02-16 | G           | 503 61 00-03 | B           |              |             |
| 501 52 52-02 | S           | 503 20 21-82 | D           | 503 61 00-04 | B           |              |             |
| 501 52 61-02 | S           | 503 20 25-20 | J           | 503 61 03-01 | D           |              |             |
| 501 52 62-01 | S           | 503 20 26-16 | A           | 503 61 33-71 | H           |              |             |
| 501 52 77-01 | S           | 503 20 32 28 | B           | 503 61 55-71 | K           |              |             |
| 501 52 78-01 | M           | 503 20 34-16 | K           | 503 61 56-01 | K           |              |             |
| 501 52 79-02 | M           | 503 20 80-06 | D           | 503 62 39-01 | K           |              |             |
| 501 52 81-01 | M           | 503 21 06-16 | K           | 503 65 09-01 | L           |              |             |
| 501 52 82-01 | S           | 503 21 06-22 | E           | 503 65 27-01 | O           | N            |             |
| 501 52 84-02 | T           | 503 21 28-06 | KM          | 503 66 28-09 | B           |              |             |
| 501 52 88-01 | E           | 503 21 28-10 | A           | 503 66 84-03 | M           |              |             |

1 Compl = 501 52 26-06  
2 Compl = 501 49 48-02

Set of gaskets  
Dichtungssatz  
Jeu de joints  
Juego de juntas  
Packningssats

N = New part  
Neues teil  
Nouvelle piece  
Nueva pieza  
Ny detalj